


Telephone: (514) 858-7777

Fax: (514) 858-5666

TECHNICAL DATA SHEET

ASPSC684F





- Deep-down cleaning action is possible with the spiral design of the exclusive Vibra Groomer II brush roll.
- The Vibra Groomer II produces an effective wave action that vibrates deeply embedded dirt.
- Count on the 18 Quart Reusable High-Capacity, Shake-Out Bag Upright with Replaceable Bristle Strips for continuous, deep cleaning every time.



Specifications

Colour	Red/Gray
Туре	Upright
Width	12"
Amperes	7
Manufacturer	Electrolux