


Radiance

Dishwasher Rinsing Agent

TECHNICAL DATA SHEET



DESCRIPTION

RADIANCE dishwasher rinsing agent contains surfactants that break down the surface tension of water, so that water droplets cannot form on freshly cleaned tableware allowing dishes, glasses and cutlery to dry sparkling clean and spot-free.

RADIANCE formula contains special softening, chelating and dispersing agents that inhibit precipitation of insoluble salts on tableware, dishwasher walls and parts, yielding superior washing performance in soft and hard water.

RADIANCE contains de-foaming agents to make the water run off the dishes faster and more effectively, thus eliminating water spots and streaks in addition to reducing drying time considerably.

DIRECTIONS FOR USE

For use in machines equipped with automatic rinse injectors, keep the liquid reservoir filled according to manufacturer's recommendations.

Adjust feed rate of rinse additive to smallest amount that gives desired results.

For dishwashers without rinse injectors, add two teaspoons of rinse additive to the final rinse.

For hand dishwashing, use two teaspoons per 3 gallons of hot water.

Consult a GILCO representative for more information.

PROPERTIES

Appearance :	Liquid
pH (1% solution) :	~7.0
Solubility :	Instant
Fragrance :	Typical
Color	Blue

PRECAUTIONS

PACKAGING CODE
 4 L
 4 x 4 L
 20 L
 200 L

Do not use on food contact surfaces. Do not store in food processing or food storage areas. Do not contaminate food products.

ALL SURFACES SUBJECT TO CONTACT WITH FOOD MUST BE RINSED WITH POTABLE WATER BEFORE USE.